

# HEAVY DUTY ELECTRIC FRYER 2 X 12L WITH FAUCET







## GENERAL SPECIFICATIONS

- 1.5 mm thick AISI 304 stainless steel top
- Flush top setting with secure fixing screws
- Installation gap behind the equipment
- Easy access from front panel to all major components
- Stainless steel with satin Scotch-Brite finish
- Adjustable feet

#### INSTALLATION OPTIONS

- standalone (fixed on a base w/ or w/o door)
- cantilever
- on concrete plinth

| Power                   | 22.0 kW (2 x 11.0 kW) |
|-------------------------|-----------------------|
| Connection              | 400V / 50Hz / 3Phase  |
| Net Weight              | 40 kg                 |
| Machine Dimensions      | B800 x D700 x H280 mm |
| <b>Protection Class</b> | IP-X3                 |
| HS Customs Code         | 8419818090            |
| EAN Code                | 8719632123811         |
| Article Number          | 09394999              |



## ELECTRIC FRYER

- Well capacity 8 12L (W300 x D325 x H240 mm)
- Oil expansion recess incorporated in the top
- Continuous seal of the well on the top by robotic welding
- Interior of one piece deep drawn well with rounded corners for ease of cleaning
- Thermostatic regulation of oil temperature up to a maximum of 190°C
- Supplied with full size baskets per each well.
- Safety thermostat with manual reset standard on all units for each well
- Armored heating elements with low power density ensures optimum service life for the oil
- Heating element can rotate by 90°C for ease of cleaning on electric models
- Easy draining with through a tap positioned on the front the well

# ACCESSORIES

- Full sizes baskets for 12L wells 2 Pcs
- Lid with ergonomic handle for 12L wells 2 Pcs
- Baskets holder and base grid for 12L wells 2Pcs





