

## HEAVY DUTY GRIDDLE GROOVED CHROME | SINGLE | GAS



<b>Power</b>	7.0 kW
<b>Connection</b>	1/2" G25 Natural Gas / G30 LPG
<b>Net Weight</b>	20 kg
<b>Machine Dimensions</b>	W400 x D700 x H280 mm
<b>HS Customs Code</b>	8419818090
<b>EAN Code</b>	8719632126102
<b>Article Number</b>	09396008



### GENERAL SPECIFICATIONS

- 1.5 mm thick AISI 304 stainless steel top
- Flush top setting with secure fixing screws
- Installation gap behind the equipment
- Easy access from front panel to all major components
- Stainless steel with satin Scotch-Brite finish
- Adjustable feet

### INSTALLATION OPTIONS

- standalone (fixed on a base w/ or w/o door)
- cantilever
- on concrete plinth

### GAS FLOW RATE

23884 Btu/hr	6020 kcal	
G20 Natural gas	20mbar	0.74 m <sup>3</sup> /h
G30/G31 LPG	28-30/37 mbar	0.55 kg/h
G30 LPG	50 mbar	0.55 kg/h

### GAS GRILL

- Plate surface W344 x D458 mm
- Removable stainless steel high splash guards on the rear and sides of cooking surface for operational comfort
- Drain hole on top for ease of operation and cleaning
- "Ribbed" cooking surface "hard chrome" coated 15 mm thick mild steel plate contained in a watertight recess for more efficient cooking
- 1.5L fat collection tray on the front side for non-stop cooking
- Thermostatic temperature control between 50-300°C
- Piezo spark ignition
- Rapid heat up with stainless steel burners: 20-200°C within 10min
- Individually controlled heating zones

### OPTIONS

- Electric Ignition

### ACCESSORIES

- Scraper - 1 Pcs

