

# HEAVY DUTY BOILING PAN 60 LITER | GAS | INDIRECT







## GENERAL SPECIFICATIONS

- 1.5 mm thick AISI 304 stainless steel top
- Flush top setting with secure fixing screws
- Installation gap behind the equipment
- Easy access from front panel to all major components
- Stainless steel with satin Scotch-Brite finish
- Adjustable feet

## INSTALLATION OPTIONS

- standalone (fixed on a base w/ or w/o door)
- cantilever
- on concrete plinth

### GAS FLOW RATE

<b>37532</b> Btu/hr	<b>9460</b> kcal	
G20 Natural gas	20mbar	1.16 m³/h
G30/G31 LPG	28-30/37 mbar	0.87 kg/h
G30 LPG	50 mbar	0.87 kg/h

Power	11.0kW
Connection	1/2" G25 Natural Gas / G30 LPG 230V / 50Hz / 1Phase 100 Watt
Net Weight	67 kg
Machine Dimensions	W800 x D700 x H850 mm
HS Customs Code	8419818090
EAN Code	8719632123880
Article Number	09398050



## GAS BRATT PAN

- Indirect heating system
- 60L Capacity
- Round monoblock boiling pan 400 mm diameter
- Double skin lid with counter balanced mechanism
- High quality thermal insulated external jacket
- Energy regulation with electronic gas valve
- 2" chrome-plated draining valve with large athermic handle
- Solenoid valve and chromed swivel tap on top
- Uniformly heated in the base and side walls of the pan by integrally generated saturated steam at a temperature of 110°C and a pressure of 0.4 bar in the jacket
- 3/4" hot, cold or mixed water supply for filling the pan through control knob
- Relief valve to evacuate excess air in the jacket
- Micro perforated high performance stainless steel burners with flame failure device on gas models
- Electronic ignition system / indicator lamp
- Double skin flue with removable cast iron grid

#### OPTIONS

Autoclave lid





